



USER INSTRUCTIONS

3950 **Horizon** **6 DIGIT CODES**

For full fitting, operating and
programming instructions please visit
www.lowe-and-fletcher.co.uk

Lowe & Fletcher Ltd
Moorcroft Drive
Wednesbury, West Midlands
WS10 7DE, England

T: + 44 (0) 121 505 0400

F: + 44 (0) 121 505 0420

E: sales@lowe-and-fletcher.co.uk

W: www.lowe-and-fletcher.co.uk

Public Mode

Lock

ENTER USER CODE
(6 DIGITS)



CONFIRM CODE
(6 DIGITS)



PUSH IN HANDLE
TO LOCK



ERROR
TRY AGAIN

Error



Errors will time-out after 4 seconds.
Unfinished instructions will time-out after 4
seconds. Always wait for LED lights to finish
before pressing next key.

Private Mode

Unlock


USER OR
MASTER CODE



HANDLE
POPS-OUT
TURN HANDLE
TO OPEN



PUSH IN HANDLE
TO LOCK



Change User Code

LOGO



OLD USER CODE



02



ENTER
NEW USER CODE
(6 DIGITS)



CONFIRM
NEW USER CODE
(6 DIGITS)



PUSH IN HANDLE
TO LOCK

Emergency Key Override

INSERT MASTER KEY OVERRIDE & TURN 90°
EITHER CLOCKWISE OR ANTI-CLOCKWISE



TURN KEY BACK 90° TO ORIGINAL
POSITION & REMOVE FROM LOCK