

Horizon Digital Combination Locks

4 DIGIT CODES

Play Instructional Video 

Public Mode

Lock

ENTER USER CODE
(4 DIGITS)



CONFIRM CODE
(4 DIGITS)



PUSH IN HANDLE
TO LOCK



ERROR
TRY AGAIN

Unlock

USER OR MASTER
CODE



HANDLE
POPS-OUT
TURN HANDLE
TO OPEN

Private Mode

Unlock


USER OR MASTER
CODE



HANDLE
POPS-OUT
TURN HANDLE
TO OPEN



PUSH IN HANDLE
TO LOCK



Change User Code

LOGO



OLD USER CODE



02



ENTER
NEW USER CODE
(4 DIGITS)



CONFIRM
NEW USER CODE
(4 DIGITS)



Horizon
digital lock


Horizon Digital Combination Locks

4 DIGIT CODES

Play Instructional Video 

Emergency Key Override

INSERT MASTER KEY OVERRIDE & TURN 90°
EITHER CLOCKWISE OR ANTI-CLOCKWISE



TURN KEY BACK 90° TO ORIGINAL
POSITION & REMOVE FROM LOCK

Error



Errors will time-out after 4 seconds.
Unfinished instructions will time-out after 4
seconds. Always wait for LED lights to finish
before pressing next key.

LOWE & FLETCHER LTD

Moorcroft Drive, Wednesbury, West Midlands, WS10 7DE, UK
Tel: +44 (0) 121 505 0400
Email: sales@lowe-and-fletcher.co.uk
www.lowe-and-fletcher.co.uk

LOWE & FLETCHER, INC.

650 Airport Place, Norton Shores, MI-49441, Michigan, USA
Tel: +1 (616) 994 0490
Email: sales@loweandfletcherinc.com
www.loweandfletcherinc.com

EURO-LOCKS SA NV

Rue de la Fontaine 8, 6600 Bastogne, Belgium
Tel: +32 61 212 261
Email: sales@euro-locks.be
www.euro-locks.be

EURO-LOCKS SA

1 Rue du Stade, 57730 Folschviller, France
Tel: +33 (0) 3 87 92 61 11
Email: euro-locks@euro-locks.fr
www.euro-locks.fr

EURO-LOCKS GMBH

Am Bruchwald 22, 66280 Sulzbach/Neuweiler, Germany
Tel: +49 (0) 6897 9072 0
Email: vertrieb@euro-locks.de
www.euro-locks.de

EURO-LOCKS SP. Z O.O.

ul. Pawła 29, 41-708 Ruda Śląska, Poland
Tel: +48 (32) 344-78-70, -82, -84
Email: sekretariat@euro-locks.pl
www.euro-locks.pl