

# Zenith Digital Combination Locks

## Public Mode

Play Instructional Video 

Public Mode

**To Lock**

**To Unlock**

ENTER CODE  
(4 DIGITS)



CONFIRM CODE  
(4 DIGITS)



TURN HANDLE  
ENSURE LOCKING

ENTER CODE  
(4 DIGITS)



TURN HANDLE  
TO OPEN

Error



Errors will time-out after 4 seconds.  
Unfinished instructions will time-out after 4 seconds. Always wait for LED lights to finish before pressing next key.



Zenith   
digital combination locks

**LOWE & FLETCHER LTD**

Moorcroft Drive, Wednesbury, West Midlands, WS10 7DE, UK  
Tel: +44 (0) 121 505 0400  
Email: sales@lowe-and-fletcher.co.uk  
www.lowe-and-fletcher.co.uk

**LOWE & FLETCHER, INC.**

650 Airport Place, Norton Shores, MI-49441, Michigan, USA  
Tel: +1 (616) 994 0490  
Email: sales@loweandfletcherinc.com  
www.loweandfletcherinc.com

**EURO-LOCKS SA NV**

Rue de la Fontaine 8, 6600 Bastogne, Belgium  
Tel: +32 61 212 261  
Email: sales@euro-locks.be  
www.euro-locks.be

**EURO-LOCKS SA**

1 Rue du Stade, 57730 Folschviller, France  
Tel: +33 (0) 3 87 92 61 11  
Email: euro-locks@euro-locks.fr  
www.euro-locks.fr

**EURO-LOCKS GMBH**

Am Bruchwald 22, 66280 Sulzbach/Neuweiler, Germany  
Tel: +49 (0) 6897 9072 0  
Email: vertrieb@euro-locks.de  
www.euro-locks.de

**EURO-LOCKS SP. Z O.O.**

ul. Pawła 29, 41-708 Ruda Śląska, Poland  
Tel: +48 (32) 344-78-70, -82, -84  
Email: sekretariat@euro-locks.pl  
www.euro-locks.pl

**L&F** A Lowe & Fletcher Group Company